



PRECISION MEASUREMENT ENGINEERING, INC
1487 Poinsettia Ave., Suite 129
Vista, CA 92081

TEL - (760)727-0300
FAX - (760)727-0333
www.pme.com

miniDOT Anti-Fouling Copper Kit includes:

- 1 Cu Wire Mesh Disc
- 1 Cu Plate
- 1 Nylon Ring
- 3 Phillips Pan Head Screws

How to install the Copper Plate on a miniDOT:

1. Use a screwdriver to remove 3 of the 6 screws (every other one). Do NOT remove all screws. At least 3 must remain screwed in at all times.

****Save the ss316 screws. They will be needed if the Cu plate is removed.***

2. Position the Copper Plate faced down so that the notches in the Copper Plate perfectly align over sensing spot and over the screw holes.

3. Install the three pan head screws included in the kit. *Gently hand-tighten only.*

