



**All-in-one weather sensor with measurement of temperature, relative humidity, precipitation intensity, precipitation type, precipitation quantity, air pressure, wind direction, wind speed and radiation.**

- **Parameters measured**  
Temperature, relative humidity, precipitation intensity, precipitation type, precipitation quantity, air pressure, wind direction, wind speed, radiation
- **Measurement technology**  
Ultrasonic/Wind, NTC/T, Capacitive/RH, MEMS capacitive/Pressure, Thermopile/Radiation, Radar/Precipitation
- **Product highlights**  
Compact all-in-one weather sensor, low power, heater, aspirated radiation shield, maintenance-free operation, open communication protocol
- **Interfaces**  
RS485, 2-wire, half-duplex
- **Article number**  
8380.U01

From the WS product family of professional intelligent measurement transducers with digital interface for environmental applications. Integrated design with ventilated radiation protection for measuring: Air temperature, relative humidity, precipitation intensity, precipitation type, precipitation quantity, air pressure, wind direction, wind speed and radiation. One external temperature sensor is connectable.

# Technical Data

WS700-UMB Smart Weather Sensor



General	
Dimensions	Ø approx. 150 mm, height approx. 317 mm
Weight	Approx. 1.5 kg
Interface	RS485, 2 - wire, half - duplex
Power supply	4...32 VDC
Operating temperature	-50...60°C
Operating rel. humidity	0...100% RH
Heating	40 VA at 24 VDC
Cable length	10 m
Protection level housing	IP66
Mast mounting suitable for	Mast diameter 60 - 76 mm

Temperature	
Principle	NTC
Measuring range	-50...60 °C
Unit	°C
Accuracy	±0.2°C (-20...50 °C), otherwise ±0.5 °C (> -30 °C)

Relative humidity	
Principle	Capacitive
Measuring range	0 ... 100 % RH
Unit	% RH
Accuracy	±2 % RH

Air pressure	
Principle	MEMS capacitive
Measuring range	300 ... 1200 hPa
Unit	hPa
Accuracy	±0.5 hPa (0...40 °C)

Wind direction	
Principle	Ultrasonic
Measuring range	0 ... 359.9 °
Unit	°
Accuracy	< 3° RMSE > 1.0 m/s

Wind speed	
Principle	Ultrasonic
Measuring range	0 ... 75 m/s
Unit	m/s
Accuracy	±0.3 m/s or ±3 % (0...35 m/s) ±5 % (>35 m/s) RMS
Resolution	0.1

Precipitation intensity	
Resolution	0.1 mm/h

# Technical Data

WS700-UMB Smart Weather Sensor



Precipitation quantity	
Resolution	0.01
Reproducibility	Typical >90 %
Measuring range drop size	0.3...5 mm
Type of precipitation	Rain/snow

Radiation	
Unit	W/m <sup>2</sup>
Accuracy	5%
Response time (95%)	< 1 s
Spectral range	300 to 1100 nm
Measuring range	1400 W/m <sup>2</sup>