



INSTRUCTION SHEET

Rhodamine WT Sensor

Safety Precautions

Please read this entire instruction sheet before operating this sensor. Pay particular attention to all danger and caution statements. Failure to do so could result in serious injury to the operator or damage to the sensor.

Do not use or install this sensor in any manner other than that which is specified in this instruction sheet.

Use of Hazard Information

If multiple hazards exist, this instruction sheet will use the signal word (Danger, Caution, Note) corresponding to the greatest hazard.

DANGER—Indicates a potentially or imminently hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION—Indicates a potentially hazardous situation that may result in minor or moderate injury or instrument damage.

NOTE—Information that requires special emphasis.

Precautionary Labels

Read all labels and tags attached to the instrument. Personal injury or damage to the instrument could occur if not observed.



This symbol, if noted on the instrument, references the instruction sheet for operational and/or safety information.

Introduction



The Rhodamine WT sensor is available as an option on the DataSonde 4a, 4X or MiniSonde 4a. The sensor is an in-situ optical fluorometer that determines rhodamine concentration in a given water sample. The sample is irradiated using green (550 nm) light. The Rhodamine WT sensor absorbs the green light energy and fluoresces or emits red (590–715 nm) light. The sensor directly measures the amount of red light emitted by the rhodamine in the water sample. The multiprobe can either display the rhodamine signal as a scaled voltage from 0–5 V or as a concentration from 0–1000 ppb.

Maintenance

Important Note: Do not use organic solvent solutions such as acetone or methanol with the Rhodamine WT sensor. These solvents will damage the plastic housing cap.

The Rhodamine WT sensor requires periodic maintenance to remove contaminants such as oil, biological growth, dirt, etc. Sensor maintenance should be conducted after every deployment cycle, adjusting the deployment cycle length to account for the degree of fouling that occurs in the area. Maintenance should also be done before and after calibration.

1. Flush the entire instrument with clean fresh water. Use soapy water and a soft brush to clean the outside surfaces of the instrument.
2. Soak the entire instrument in freshwater for at least 30 minutes.
3. Visually inspect the optical windows. Use optical tissue or a cotton swab with soapy water to clean the optical windows. Rinse with freshwater.

Parameter Setup

Important Note: The Rhodamine WT sensor has been characterized at the factory to display linear behavior between the gain zones. **DO NOT** change the values stored in the Sensor Setup tab. This may result in non-linear readings.


Note: If a Hydrolab Surveyor is used to display the voltage in the X10 or X100 fixed gain settings or if the user changes the gain settings, then the Surveyor may require a **RESET:HISTORY** reset in order to display the proper resolution.

The Rhodamine WT sensor functions using one of three gain settings:

- X1 gain provides a range of 0 to 1000 ppb
- X10 gain provides a range of 0 to 100 ppb
- X100 gain provides a range of 0 to 10 ppb

The factory-default will automatically switch the gain as needed. If necessary, the gain settings may be fixed to one of the three gain settings described above.

1. Connect the sensor to a PC.
2. Start Hydras 3LT. Wait for Hydras 3LT to establish communications with the sensor. Click the **OPERATE SONDE** button.
3. Click the Parameter Setup tab and select Rhodamine ppb.



4. To enable auto gain, enter zero. To enable a fixed gain, enter 1 for X1, 10 for X10, or 100 for X100. In most cases, it is recommended to leave the sensor in auto gain mode for maximum dynamic range.
5. Click the **SAVE SETTINGS** button.

Rhodamine WT Sensor Calibration

Rhodamine concentration is associated with an output voltage. This output voltage from the sensor may be displayed directly or scaled to reflect a user-defined concentration in ppb.

There are two standard methods for calibrating the Rhodamine WT sensor. Each method requires a 2-point calibration. The first point must be 0 ppb. The second point should be a non-zero value which is at least three times larger than the zero sample but within the linear range of the sensor. It is recommended that the non-zero sample represents an average or approximately 50% of the range of concentration the user expects to monitor. A Solid Standard is recommended for defining repeated non-zero samples.

Method 1

Use this method when a known calibration standard is applied to the sensor.

1. Connect the sensor to a PC.
2. Start Hydras 3LT. Wait for Hydras 3LT to establish communications with the sensor. Click the **OPERATE SONDE** button.
3. Click the Calibration tab and select Rhodamine ppb.

The screenshot shows the 'HYDROLAB - COM 1' software window with the 'Calibration' tab selected. The interface includes a menu bar with 'System', 'Online Monitoring', 'Log Files', 'Parameter Setup', 'Calibration', 'Settings', and 'Software'. Below the menu bar is a grid of parameter selection buttons: SpCond [mS/cm], SpCond [µS/cm], Res [kΩ-cm], Sal [ppt], TDS [g/l], DO% [Sat], DO [mg/l], BP [mmHg], pH [Units], ORP [mV], Rhodamine [ppb], Rhodamine [Volts], and Dep200 [meters]. The 'Rhodamine [ppb]' button is highlighted. The main display area shows the following data:

- Current Value: 0.13* [ppb]
- 5/4/2004 8:54:35 AM
- Temp: 23.54 [°C]
- Voltage: 0.006 [Volts]

Below this data is a text input field labeled 'Rhodamine [ppb]' containing the value '0.00'. Underneath the input field is the label 'Enter standard (ppb):'. At the bottom of the main display area is a 'Calibrate' button. The system tray at the bottom right of the window shows the time '8:54:35 AM'.

4. Place the sensor into a 0 ppb baseline solution. Enter zero in the Rhodamine ppb field.
5. Press **CALIBRATE**. "Calibrate Successful!" screen will be displayed.


- Place the sensor into a known ppb solution or use the Solid Standard. Enter the rhodamine value in the Rhodamine ppb field.
- Press **CALIBRATE**. A "Calibrate Successful!" screen will be displayed.

Method 2

Note: Voltage values for zero and non-zero ppb rhodamine samples are similar between different sensors, but not identical. When using Method 2, every sensor will have a unique voltage value for a given concentration.

Use this method when you have voltage values for both a "zero" and "non-zero" ppb rhodamine sample. Typically, both zero and non-zero samples are measured using the sensor to get voltages and then the same samples are measured using a calibrated laboratory fluorometer to get "true" values for the rhodamine concentration.

- Connect the sensor to a PC.
- Start Hydras 3LT. Wait for Hydras 3LT to establish communications with the sensor. Click the **OPERATE SONDE** button.
- Click the Calibration tab and select Rhodamine Volts.



- Enter zero into the Rhodamine ppb field.
- Enter the corresponding voltage into the Voltage field.
- Press **CALIBRATE**. A "Calibrate Successful!" screen will be displayed.
- Enter the non-zero value into the Rhodamine ppb field.
- Enter the corresponding voltage into the Voltage field.
- Press **CALIBRATE**. A "Calibrate Successful!" screen will be displayed.

Calibration Performance Check

The optional Solid Standard can be used as a calibration performance check. The Solid Standard can establish a correlation between a known concentration found from laboratory measurement of a sample whose signal output voltage from the Rhodamine WT sensor is also known. The Solid Standard can also be used to check the sensor stability periodically.

The Solid Standard is a solid fluorescent device placed over the optical head. A flat head screwdriver is used to adjust the magnitude of the fluorescent response from 0 to approximately 1000 ppb. The Solid Standard can be used to establish a correlation between a known concentration and the fluorometer output voltage. It can also be used to check the sensors stability and/or check for the effects of bio-fouling.

Using the Solid Standard

1. Make sure the optical surface of the sensor is clean and dry.
2. Immerse the sensor into a known Rhodamine WT dye solution. Note the sensor output voltage.
3. Clean and dry off the sensor. Place the Solid Standard on the optical end of the sensor.
4. Rotate until the Solid Standard is properly aligned with the indexing mark on the sensor. A "clicking" noise will be heard when aligned properly.
5. Adjust the Solid Standard to produce the same output voltage from the sensor as in step two. Use the provided screwdriver to adjust the screw located on the side of the cube. Adjust the screw clockwise to increase the signal, and counter-clockwise to decrease the signal.
6. For future use, this Solid Standard can be used as a verification device for this sensor.

Note: Solid Standards give unique responses for a given sensor. A given setting on a Solid Standard should only be used for the sensor on which it was calibrated.

Specifications

Specifications are subject to change without notice.

Minimum Detection Limit	0.1 ppb
Dynamic Range	Low sensitivity: 0–1000 ppb; Medium Sensitivity: 0–100 ppb; High Sensitivity: 0–10 ppb
Linearity	0.99 R ²
Resolution	0.01 ppb
Range	0–1000 ppb
Accuracy*	± 3% of reading or ± 0.1 ppb, whichever is greater
Resolution	0.01 ppb
Warranty	Sensor is covered by a 1 year warranty

* The following exceptions are taken to the specified accuracy under IEC 1000-4-3:1996: Vertically-oriented radiated interference of 10V/m between 20 and 600 MHz has been observed to cause measurement shifts up to 5V (with corresponding shifts in the analyte reading) when the Sonde with this sensor was exposed to the stated field. Horizontally-oriented radiation interferences of 10V/m between 50 and 150 MHz and between 450 and 600 MHz has been observed to cause measurement shifts up to 140 mV (with corresponding shifts in the analyte reading) when the Sonde with this sensor was exposed to the stated field. Radiated interference testing was performed in air. Normal operation of the Sonde under water is expected to decrease the impact of the radiation interference.

Rhodamine WT Sensor

Accessories

Description	Cat. No.
Solid Standard	007205
Dye-Rhodamine, 8 oz. 21.33% \pm 2.5% (w/w)	007273



FOR TECHNICAL ASSISTANCE, PRICE INFORMATION, AND ORDERING:

In the U.S.A. – Call toll-free 800-949-3766

Outside the U.S.A. – Contact the HYDROLAB office or distributor serving you.

On the Worldwide Web – www.hydrolab.com

HYDROLAB World Headquarters

P.O. Box 389, Loveland, CO 80539-0389

Telephone: (970) 669-3050

FAX: (970) 461-3921